



Installation of the Media Enclosure

Parts included in this kit:

- (1) Media enclosure
- (4) #8 screws

Tools you will need for installation:

- Phillips screwdriver
- Drill and 1/8" drill bit

Steps:

1. Unpack the media enclosure.
2. Place enclosure on the countertop when you like it.
3. Unscrew the top cover (4 screws, 2 on each side) using the screwdriver. Separate the two pieces. (Figure 1)



Figure 1

4. Use a marker or pen to mark the holes that are located in the bottom enclosure in order to drill holes for the screws. Move the unit and drill 1/8" holes into the countertop. (Figure 2)



Figure 2

5. Once the holes are drilled, replace the enclosure and screw the #8 screws through the enclosure into the countertop, securing the enclosure.
6. Mount the HP computer (ordered separately) into the media enclosure box by sliding the back of the stand in first, followed by the front. Slide the front of the stand as far front as possible until it butts up against the lip inside the media enclosure. (Figure 3)



Figure 3

7. Slide the top cover over the bottom base unit until it is all the way back and lined up with the screw holes on the sides. Make sure the front clears the media cards. (Figure 4)



Figure 4

8. Replace the screws from the sides of the media enclosure. (Figure 5)



9. Plug in the 4 pin power supply into the back of the enclosure and USB cord into the computer. (Figure 6)

